

The following instructions will guide you through the process of attaching the Dyna-Lift to the kiln base and lid handle. If you have any questions or encounter difficulty assembling the stand or attaching the Dyna-Lift please contact us at 989-856-2281 or info@evenheat-kiln.com. We're here to help.

Tools Needed:

1/8" Allen Wrench (provided)
7/16" Wrench

Step 1:

Place the Dyna-Lift against the back of the kiln base as shown. You do not need to remove the kiln from the base to accomplish this. However, the kiln must be positioned in such a way as the back of the kiln does not hang over the base.

Fasten the Dyna-Lift to the kiln base using the included hardware. To do so, place a lockwasher on each bolt followed by a flat washer and thread each of the 8 bolts through the Dyna-Lift mounting bracket and into the base. Tighten each using the 7/16" wrench.



Step 2:

Lift the Dyna-Lift arm up as far as possible and install the lifting springs as shown. When installing the springs the spring ends should go into the grooves created by the collars.



Step 3.

This step requires that you lower the lift arm while it is under spring pressure. Because of this we recommend that 2 people are used for this portion of the assembly.

Using the included 1/8" Allen wrench remove one of the collars on the kiln lid handle and remove the lid handle bar.

Lower the lift arm to the handle and re-install the lid handle bar while also placing it through the lift arm link as shown.

Re-install the collar and tighten securely.



Your GTS 23 Dyna-Lift lift assist is now completely installed.

